

<b>Cotton Stuffed Tuck &amp; Roll</b>		
Finish Width	FW	
Finish Length	FL	
Cut Width	CW	
Cut Length	CL	
Pleat Width	PW	
Pleat Number	P#	
Seam Allowance	SA	
Seam Allowance Total	SAT	
Roll Allowance	RA	
Fold Allowance	FA	
Total Fold Allowance	TFA	
Plot Point 1	PP1	
Plot Point 2	PP2	
Base Width	BW	
Base Shrinkage	BS	
Base Mark 1	B1	
Base Mark 2	B2	

Date:	Project:
$FW = PW \times P\#$	
$CW = P\# \times (PW + RA) + SAT + TFA$	
$CL = FL + SAT$	
$PW = FW \div P\#$	
$P\# = FW \div PW$	
$SAT = SA \times 2$	
$RA = 1/2"$ I usually use this , RA adjusts the puffiness of the pleat	
$FA = 1/2"$ I usually use this	
$TFA = (P\# - 1) \times FA$	
$PP1 = SA + PW + RA + (1/2 FA)$	
$PP2 = PW + RA + FA$	
$BW = (P\# \times BS) + FW + SAT$	
$3/8"$ on $2"$ peats.	
$B1 = SA + PW + BS + (1/2 FA)$	
$B2 = PW + BS$	



Calculations / Notes

